

If you have ever opened a wall and watched a screwdriver sink into what looks like solid wood, you know the particular sinking feeling that comes with termite damage. The repair itself is not rocket science, but the judgment calls around it separate sturdy, long-lasting outcomes from repeat problems. I have been on too many jobs where a home already “fixed” a year earlier was back to square one because the wrong priorities drove the work. The stakes are real: you are not just patching wood, you are restoring the load paths that keep floors flat, doors aligned, and roofs where they belong.

This guide walks through the common mistakes I still see with termite damage repair and how to approach the work so it holds up. It covers the whole spread, from termite wall repair and termite sill plate repair to floor joists, beams, subfloors, attic wood, and the drywall you will inevitably need to put back after termite treatment. Whether you plan to tackle small areas yourself or you are vetting termite repair services, the principles are the same.

## **Why termite repairs go sideways**

Termites are patient, quiet, and thorough. People are the opposite when a schedule and budget press. Most failed termite damage restoration jobs trace back to one of three root problems. Someone treated the insects but ignored moisture and access. Someone made pretty surfaces but left structural weak points. Or someone replaced wood without understanding how that piece participates in the structure. These patterns show up in crawlspaces, basements, and attics alike.

I start every repair conversation with scope, not solutions. Where did the termites travel, what fed them, and what role do the damaged components play? A crippled stud behind a closet may look like a small problem, until you realize it sits under a point load from a girder. Likewise, a chewed-up baseboard looks dramatic but often matters less than the hidden sill behind it. A little patience on the front end saves thousands on the backside.

## **Mistake 1: Skipping a full inspection and mapping**

Treating the colony, then running straight to the worst-looking board, is a classic misstep. Subterranean termites usually advance along predictable routes: soil, foundation cracks, sill plates, rim joists, then into studs and headers. Drywood termites behave differently, starting in accessible dry lumber, including attic rafters.

A good termite wood repair plan begins by mapping travel paths. I probe with an awl every 6 to 12 inches along suspect members, especially at ends and connections. I look for frass, irregular galleries, and paper-thin outer shells. In finished spaces, I use a borescope through the back of baseboards or under outlet covers. Where load is in question, I do not guess. I remove more finish to see what matters.

Pay special attention to spots that swing the most structural weight: floor joist bearings, sill plates at long exterior runs, and beams supporting stair openings or chimneys. With termite framing repair, you can only fix what you can see.

## **Mistake 2: Treating termites but not fixing moisture and access**

Termites need water. Crawlspaces humidity, leaky hose bibs, grade sloping toward a foundation, or a bathroom with a chronic drip all invite them back. Even the best termite damage repair will not last if moisture stays high.

I have walked into crawlspaces at 85 percent relative humidity with fallen insulation and dark wood. In those spaces, termites are a symptom. Before you repair, redirect downspouts, cut soil that has bridged to siding, add a

vapor barrier, and bring humidity under 60 percent. If you cannot keep the space dry, your termite structural repair becomes a revolving door.

### **Mistake 3: Cosmetic patches on structural members**

Spackling holes and swapping baseboards does not fix crushed load paths. I once consulted on a house where a kitchen wall looked crisp and new, yet the floor still sagged 5/8 inch over 12 feet. The drywall was freshly painted, but the studs had been eaten to half thickness. The contractor skimmed, sanded, and called it done. The cabinet doors told the truth.

Cosmetic work follows structure, not the other way around. With termite wall repair, if a stud under a header is compromised, reinforce or replace the stud before you worry about the drywall. If a rim joist is hollow, reframe that segment and reflash correctly. It is the boring, hidden labor that keeps finish work aligned and crack-free over time.

### **Mistake 4: Guessing on species, extent, and timing**

Drywood and subterranean termites chew differently and live differently. Drywood colonies work inside dry lumber and often leave piles of frass inside attics or behind trim. Subterraneans build shelter tubes and depend on soil moisture. The sequence for repair shifts with the species. For drywood, you can often isolate, remove, and spot treat the infected wood. For subterraneans, you need soil treatment or baiting, moisture correction, and then structural work.

Homeowners sometimes jump to repair before confirming the active status of the colony. That can be fine when stabilizing a beam or a joist that cannot wait, but you should coordinate closely with your pest control tech. If you are planning termite drywall repair after termite treatment, you do not want to close up cavities before the pest company verifies that activity has stopped. A ten-minute debrief between trades saves hundreds in callbacks.

### **Mistake 5: Using the wrong materials and connectors**

I still see untreated wood installed on a concrete foundation, plain nails where structural screws are required, and sistered members with too few fasteners to act compositely. When you replace a sill, use pressure-treated lumber rated for ground contact and a sill gasket or capillary break to keep moisture from wicking up. Anchor bolts or straps need to meet the spacing and edge clearances in your local code. For termite beam repair, especially in older homes with undersized members, engineered lumber is often a smart upgrade because it gives you uniform strength, long spans, and straight bearing surfaces.

Fastener choice matters as much as the lumber. To make a sistered joist share load, I install a staggered pattern of structural screws, often 3/8 inch lags or engineered fasteners, at 12 to 16 inches on center, plus construction adhesive. Simply toe-nailing at the ends does not transfer bending. Likewise, post and beam repairs need full bearing with shims or steel plates, not scraps of cedar shake or broken tile. I still find the latter in crawlspaces.

### **Mistake 6: Bad sequencing with pest control and finishes**

Termite repair services and exterminators need to work in a specific order. Generally, stop the bugs and correct moisture first, then open up and repair, and finally close, prime, and paint. The exception is emergency shoring or bracing, which happens as soon as you detect excessive deflection or crushing.

Drywall is the battleground for sequencing. With termite drywall repair after termite treatment, you want enough openings for the exterminator to treat and verify, but you do not want to leave open cavities for weeks in humid weather. I often cut clean, rectangular access panels and number them, store them flat, and reinstall with backer cleats. This approach avoids oddly shaped patches and preserves the original texture.

## **Mistake 7: Half-measures on critical components**

Termite floor joist repair is a frequent candidate for half measures. People sister three or four feet of a twelve-foot joist where the end is chewed, then wonder why the floor still bounces. If damage is concentrated at the bearing end, a full-length sister, or at least a sister that extends well beyond the middle third of the span, is usually required. Where you cannot run full length due to plumbing or ductwork, consider a flitch plate or engineered repair with a licensed engineer's input.

For termite sill plate repair, replacing a foot here and there can work if joints land over solid support and you interlock properly. But when the rim is compromised across a long run, it is cleaner and more reliable to do a continuous replacement in sections with temporary jacking. The same principle applies to termite beam repair. Sistering a main beam with a short scab at midspan does little. Add a properly supported post, a full-length LVL alongside the original, or both.

## **Mistake 8: Ignoring permits, engineering, and inspections**

Not every termite framing repair requires a permit. Many do. When you change bearing members, modify foundations, or replace significant structural components, you are in permit territory in most jurisdictions. Pulling the permit does two things that matter. It forces a second set of eyes on your plan, and it creates an inspection record that helps during resale and insurance claims.

On a recent 1940s bungalow, the front half had settled an inch. Termites had chewed three studs below a porch header and the sill under them. We templated temporary walls, jacked 1/8 inch per day to avoid cracking the plaster, and replaced the sill and studs with treated lumber and proper anchors. The inspector's sign-off made the later appraisal straightforward. Without it, the buyer would have demanded a discount, even though the workmanship was the same.

## **Mistake 9: Forgetting finishes, ventilation, and insulation**

Termite damage repair does not stop at wood. When you repair a subfloor, you set up everything above it. Replace a strip of sheathing and forget to glue the new panel to the joists, and you will have squeaks. Reseat underlayment poorly, and your tile may crack along that seam.

In attics, termite attic wood repair often overlaps with ventilation fixes. If the ridge is starved for intake air, heat and moisture rise, wood dries out, and both termites and decay fungi get an easier foothold. When you replace rafters or collar ties, check soffit vents and baffles. Small corrections here, like cutting in two extra vents or installing a continuous soffit strip, change the long-term risk profile more than people realize.

## **Mistake 10: Skipping documentation and warranties**

Future buyers and insurers like paper. Keep the pest treatment report, photos of the damaged areas before and after, receipts for lumber and fasteners, and any engineering letters. If you use a licensed contractor, ask for the warranty in writing. I encourage homeowners to label hidden sistered members with a marker date and the material used. It helps the next person who opens that space in a decade.

# How pros scope termite structural repair

A solid plan is simple, repeatable, and transparent.

- Confirm species and stop activity: coordinate with pest control for soil treatment, foam, or spot treatment depending on species.
- Map the structure: identify load paths and prioritize sill plates, beams, joists, and headers that carry real load.
- Stabilize: shore sagging spans and set temporary supports before removal work begins.
- Replace or reinforce: choose full-length sisters, engineered lumber, or section replacement with proper connectors and bearing.
- Close and protect: reinstall drywall or sheathing, prime, paint, and address moisture and ventilation so the problem does not return.

That flow keeps termite damage restoration from turning into a game of whack-a-mole.

## Real-world examples by component

**Termite wall repair:** In a 1960s ranch, subterraneans followed plumbing into a bathroom wall. Two studs under the window were paper-thin. We supported the header with a temporary wall in the room, sawzalled nails at the sill, and removed the compromised studs. The sill under them was 30 percent gone, so we replaced that 6-foot section with pressure-treated lumber, installed new anchor straps, and reinstalled new studs tight under the header. After the pest company verified no new activity, we buttoned up the drywall. The tile surround survived, because the temporary support took the load before we cut.

**Termite floor joist repair:** In a crawlspace with 2x8s spanning 12 feet, the last 18 inches near the rim were riddled. Rather than a short scab, we slid in full-length 2x8 sisters glued and screwed to the originals, bearing fully on the sill. We added joist hangers on a new ledger where the rim was suspect. Squeaks disappeared after we re-screwed the subfloor from above.

**Termite sill plate repair:** A century-old brick foundation had a soft corner where grade had risen against the wall. The sill and rim were involved for 10 feet. We built temporary stud walls in the basement, jacked slowly to relieve pressure, cut out the decayed sill, and set a new ground-contact treated sill with a foam sill gasket. We drilled for new anchors at 4 feet on center to match local code and replaced the rim with treated 2x8. The grade outside was lowered and a downspout redirected, critical steps that made the structural work worth doing.

**Termite beam repair:** In a duplex, a built-up 2x10 beam carried the kitchen. The center third had honeycombing that collapsed under finger pressure. We added a pair of LVLs alongside, each running the full 16-foot span, bolted through with 1/2 inch carriage bolts in a staggered pattern, and set a new steel column on a poured footing. The deflection cut in half, cabinets re-aligned, and the repair provided actual redundancy.

**Termite subfloor repair:** Powdered subfloor near a dishwasher is common. Swapping only the top layer can trap odors and leave a weak edge. We traced the soft area to joist centers, cut a clean rectangle, installed 2x4 blocking on the flat under every edge, and glued and screwed new subfloor. After reseating underlayment, we reinstalled the flooring. The key was pulling the dishwasher to inspect behind and below, since leaks like to hide.



Termite attic wood repair: Drywood termites in rafters show as small piles of pellets and pockmarks along the underside of the roof. You cannot ignore rafters, even if loads seem light. A targeted rafter sister, often with 2x lumber or LVL, tied into the ridge and birdsmouth bearing, restores capacity. Where multiple rafters are involved, an engineer may call for a purlin and struts to cut effective span. At the same time, we checked the soffit vents and added baffles to ensure air could travel from soffit to ridge.

Termite framing repair in finished spaces: When studs behind plaster are involved, we preserve as much original material as possible while getting to the root. I like to cut access in straight lines to make re-plastering easier and to lath across new studs so the patch blends. A mix of consolidation epoxy for minor surface loss and full stud replacement for deeper damage keeps historic fabric where reasonable without sacrificing structure.

Termite drywall repair after termite treatment: Once the pest technician signs off, I patch with backer strips so the original drywall can be re-used as a plug, set with screws and setting compound. A couple of thinner coats, sanded properly, almost always beat a single thick coat that shrinks and shows.

## Costs, timelines, and what drives them

Prices swing by region, access, and scope, but a few ranges help set expectations:

- Localized termite wall repair that involves two to three studs and a short sill section often lands between 800 and 2,500 dollars, materials and labor.
- Termite floor joist repair with full-length sisters in a crawlspace typically runs 300 to 700 dollars per joist, more if access is tight or utilities complicate things.
- Termite sill plate repair for a typical 8 to 12 foot section, including jacking and anchoring, can range from 2,000 to 6,000 dollars depending on foundation type.
- Termite beam repair with LVLs and a new column ranges from 3,000 to 8,000 dollars, especially if a footing is needed.
- Drywall patching after treatment is usually a few hundred dollars per room unless you are matching heavy textures.

Time on site follows complexity. A two-stud wall repair is a day. A sill replacement with jacking is two to four days. Beam work with footings can stretch a week, especially when you factor in inspection windows and concrete cure time.

## DIY or call for help?

There is nothing wrong with rolling up your sleeves on minor termite wood repair. If you are swapping a small subfloor section or sistering a non-bearing stud, careful DIY work can be perfectly serviceable. But if [book Watsonville termite inspector](#) the damage touches bearing elements, if floors sag beyond a quarter inch over six feet, or if you see crushed sills and beams, it is time to search for termite repair near me and talk to pros. Look for structural termite repair near me or termite damage contractor near me and interview at least two companies. Ask what they do for temporary support, what fasteners they specify, whether they coordinate with the pest firm, and how they document work for permits.

When you type termite damage repair near me or local termite damage repair into a search bar, you will get a mix of general remodelers and specialists. For significant framing, a wood repair contractor termite damage near me who can show photos of past work in crawlspaces, attics, and basements is worth the premium. If engineering is needed, some companies bring an engineer in-house, while others have a relationship with a third party. Either model works if communication is tight.

## Small checklist to avoid the expensive mistakes

- Verify species and stop activity before you close anything.
- Correct moisture and grade so you do not invite a repeat.
- Prioritize structure first: sills, beams, joists, headers, then finishes.
- Use treated lumber where required and the right connectors in the right pattern.
- Document everything with photos, receipts, and inspection records.

Tape that list to the inside of a cabinet until the job is done. It keeps everyone, including professionals, focused on what actually matters.

## Permits, codes, and hidden constraints

A surprising number of termite damage repairs are actually code upgrades in disguise. If you open a wall and discover there are no anchor bolts holding the sill to the foundation, local rules may require you to add them when you replace the sill. Likewise, when you touch a stair opening, handrail and guard requirements can come into play. None of that should scare you off. It simply reinforces the value of a quick call to the building department or your contractor before you cut too far. If you hear the phrase like-for-like used as a blanket exemption, be cautious. Many jurisdictions restrict that to non-structural replacements.

## When the numbers do not pencil out

Every so often, you peel back enough layers to find systemic problems: multiple beams compromised, widespread termite subfloor repair needed throughout, attic rafters with long runs of damage. You can, one hundred percent, repair almost any wood frame structure. The question becomes whether it is wise at your budget. On two houses in the past decade, I advised clients to price full-scale termite damage restoration against selling as-is. In both cases, the owners still repaired, but we focused on the spine of the house first: footings, sills, main beams, and the worst joists. Cosmetic work waited. That approach kept the home safe and livable while spreading costs over time.

## Prevention that makes the repairs last

Once you repair termite damage to a house, keep your eyes open. Annual inspections by your pest company are inexpensive insurance. Termite bait stations around the perimeter help with subterraneans, and they give you a data point over time. Seal foundation cracks, keep 6 to 8 inches of clearance between soil and siding, and avoid stacking firewood against the house. If you are finishing a basement, choose treated bottom plates on slab and a capillary break. If you are insulating a crawlspace, detail it as a sealed space with proper vapor barriers and dehumidification, not a damp cave with soggy fiberglass.

I like to hand homeowners a short map of where the repairs happened and where to look each spring: that corner near the hose bib, the crawlspace entry, the attic hatch, the bathroom wall where plumbing passes. Ten minutes, once a year, heads off expensive surprises.

## **The bottom line**

Termites are persistent, but they are not mysterious. The craft of termite structural repair lies in seeing past the chewed edges to how the building carries load, then making clean, durable corrections with the right materials and steps in the right order. Take your time with the inspection. Fix moisture and access. Give structure the respect it demands. And when the job is larger than your comfort, bring in qualified help. The search terms will vary by region, but starting with structural termite repair near me or termite damage repair near me will surface the companies that do this every week, not once a year. With a sober plan, even rough damage becomes just another set of problems you solved, not the story that defined your house.