How to Spot Early Signs of Alternator Trouble Before You Get Stranded

Your car's alternator works quietly in the background, generating electricity to keep the battery charged and power the electrical systems while the engine runs. When it starts to fail, the signs are often subtle at first. Catching them early can save you from a dead battery in a supermarket car park or, worse, a breakdown on a dark Scottish B-road in January. This article walks through the warning signs in the order they typically appear, what to look for, and when to seek professional help.

Dimming or Flickering Lights

The first and most common clue is a change in your headlights or interior lights. When the alternator is working properly, the voltage it supplies stays steady. As it begins to weaken, the voltage can drop or fluctuate. You might notice your headlights dim when you slow down and brighten when you accelerate. At night, the dashboard lights may flicker, and the interior light could pulse slightly as you drive.

This happens because the alternator cannot produce enough current to keep the battery topped up and run the lights at full brightness. The battery then starts to compensate, but it drains quickly. If you see the lights behave this way, it is worth noting the conditions: does it happen only at idle, or all the time? A consistent dimness at low revs can point to a slipping belt or a failing voltage regulator inside the alternator.

Warning Lights on the Dashboard

Most modern cars have a battery-shaped warning light that glows amber or red when the charging system voltage drops too low. This light normally comes on briefly when you turn the key and then goes out once the engine starts. If it stays on while driving, or flickers on and off, the alternator is not charging the battery properly.



Some vehicles also show a general "check engine" light when the charging voltage falls outside the normal range. A diagnostic scan at a garage can confirm whether the fault code points to the alternator or another component. If you see either warning light, do not ignore it. The car might still run fine for a few miles, but the battery is slowly running down. Once it goes flat, the engine will stop and cannot restart without a jump or a new battery.

Strange Noises Under the Bonnet

An alternator contains a rotor that spins inside a stator, supported by bearings. When the bearings wear out, they produce a high-pitched whine, a grinding sound, or a rattle. You might hear this noise change pitch as the engine speed varies. A loose or worn drive belt can cause a squealing sound that is especially noticeable when the alternator is under load, such as when you switch on the headlights or the rear window heater.

If you hear a new noise that seems to come from the front of the engine, try to locate it. A failing alternator bearing will often sound metallic and rough, while a slipping belt makes a rubbery squeak. Neither will fix itself, and both will get worse until the alternator stops turning altogether. A garage can confirm the source quickly with a stethoscope or by removing the belt and spinning the pulley by hand.

Battery Voltage That Keeps Dropping

You do not need specialist equipment to check the battery voltage. A simple multimeter set to DC volts will tell you the story. With the engine off, a healthy battery should read around 12.4 to 12.7 volts. Start the engine and measure again. A working alternator should push the voltage up to between 13.8 and 14.4 volts. If the reading stays near 12 volts or climbs only slightly, the alternator is not charging.

Check the voltage again after a ten-minute drive. If it has dropped further, the alternator is draining the battery rather than replenishing it. This is a sure sign that the diodes inside the alternator have failed, allowing current to flow the wrong way. At this point, the battery will go flat within a few miles, and the car may not restart after you switch off. A garage can test the alternator output more precisely with a load tester, but a simple voltage check gives you a clear early warning.



Electrical Oddities and Slow Starts

Before the alternator gives up completely, you might notice that the engine cranks slower than usual when you turn the key. This is because the battery is not receiving enough charge to stay full. The car may start fine first thing in the morning after sitting all night, but after a short drive, the battery might be too low to restart the engine. That is a classic sign of a failing alternator: the battery itself is good, but it is not being recharged.

Other electrical gremlins can appear. The radio might cut out, the power windows may move sluggishly, or the heater fan could slow down noticeably when you switch on the headlights. These symptoms are all caused by low system voltage. A healthy alternator supplies a steady 13.5 to 14.5 volts regardless of which loads are on. If the voltage dips every time you add a load, the alternator is struggling to keep up.

A Burning Smell from the Alternator Area

A less common but serious sign is a burning smell, often described as hot metal or electrical burning. This can happen if the alternator bearings have seized and the belt is rubbing against a stationary pulley, creating friction and heat. Alternatively, an internal short circuit inside the alternator can overheat the windings, melting the insulation. If you smell something like this, pull over safely and switch off the engine. Do not drive further until a mechanic has inspected the alternator. The heat can damage surrounding hoses and wiring, and in rare cases, it can start a fire.

What to Do If You Suspect Alternator Trouble

If you notice any of the signs above, the first step is to confirm the problem with a simple voltage test or by asking a garage to check the charging system. Many independent garages will do a quick check for free or as part of a routine service. The repair itself is usually straightforward for a professional: the alternator can be rebuilt with new bearings and diodes, or replaced with a reconditioned or new unit. The belt should be inspected at the same time, because a worn belt can cause the same symptoms as a failing alternator.

Pentland Press News covers vehicle diagnostics advice for Scottish drivers, and keeping an eye on your charging system is one of the simplest ways to avoid an unexpected breakdown. A few minutes with a multimeter or a glance at the dashboard lights can save you the cost of a tow truck and the inconvenience of being stuck on a wet roadside. If you are unsure about any of the checks, a local independent garage can diagnose the issue quickly and give you a clear estimate before any work starts.



Ignoring alternator trouble rarely ends well. The battery will eventually go flat, the engine will stop, and you will need a jump start or a replacement battery just to get moving again. By then, the alternator may have damaged the battery through deep discharge, doubling the cost of the repair. Catching the problem early, when the lights first flicker or the whine first appears, gives you time to plan the repair at your convenience rather than in an emergency. If you drive in rural areas where breakdown cover can take hours to arrive, a proactive check of the charging system is especially worthwhile.

As Pentland Press News often notes in its vehicle diagnostics advice, the alternator is one of those components that works silently until it stops. Learning to read the early signs is a skill every driver can develop, and it does not require any technical training. Pay attention to the lights, listen for new noises, and check the voltage now and then. That small habit can make the difference between a planned garage visit and a roadside recovery.

Pentland Press News on social media Facebook