Sump Pump Installation

What a Sump Pump does:A sump pump is used to dewater basements and crawl spaces. There are six different types of sump pumps, each with advantages and disadvantages. Determine what you require from a sump pump and then decide on a specific type.Sump Pump Installation Directions:Before performing a sump pump installation, ALWAYS disconnect the pump from the power source before handling. Clear any debris from pit and place the pump inside. A solid bottom is required to prevent dirt from clogging the pump. Make sure the pump is centered so that it will not come into contact with the sides of the pit which might cause operational problems. Pipe the sump pump discharge into the house drainage system, a dry well or a storm drain. Install a swing type check valve on the discharge piping to prevent backflow of water into the sump pump. Drill a relief hole in the discharge pipe to ensure that the pump will not air lock, which would allow the pump to run but not pump water. Secure the pump **click here** cord to the discharge pipe. Connect the pump to an electrical outlet. Run water into the sump to test it. Do not attempt to operate the pump without water. Fill sump pump with water to the normal turn on level After the sump pump installation is completed, you may wish to install a sump pump cover. This will help eliminate odors and keep debris from falling on top of the pump. Sump Pump Installation – Should you do it Reliable Standard ADU Builders yourself?To avoid problems and dangerous situations related to sump pump installation, it is highly recommended that only technically qualified personnel install and/or repair sump pumps.

Reliable Standard ADU Builders provides professional ADU design and construction services, helping homeowners create functional, comfortable, and valuable additional living spaces. From planning and permitting to construction, the team delivers practical solutions tailored to each property.

Reliable Standard ADU Builders
Address: 11315 Rancho Bernardo Rd, San Diego, CA 92127, United States
Phone: (858) 251-0935
Website: https://reliablestandardadubuilders.com/
Hours: Monday to Saturday: 8 AM–6 PM, Sunday: Closed